

# Data Communication and Computers Lab

Lab - 03 & 04
Familiarization of Network IP & Subnetting & super netting

Submitted by:

Aaradhya Bhatiya 500108359 R2142221035

Batch - B2(Graphics & Gaming)

Submitted to:

Alok Jhaldiyal Sir

Lab 03: 29<sup>th</sup> August

#### **IPv4** Overview

- **IPv4**: The fourth version of the Internet Protocol, used to identify devices on a network.
- **Size**: 32-bit address (e.g., 192.168.1.1), divided into four octets (0-255).
- Address Classes:
  - Class A: 0-126 (Large networks) Subnet Mask: 255.0.0.0
  - Class B: 128-191 (Medium networks) Subnet Mask: 255.255.0.0
  - Class C: 192-223 (Small networks) Subnet Mask: 255.255.255.0
  - Class D: 224-239 (Multicast) Not applicable
  - o Class E: 240-255 (Experimental) Not applicable
- Loopback Range: 127.0.0.0 127.255.255.255 (used for testing).

## **Private IP Ranges**

- Class A: 10.0.0.0 10.255.255.255
- Class B: 172.16.0.0 172.31.255.255
- Class C: 192.168.0.0 192.168.255.255
- All other addresses are public.

## **Example of Private Addressing by Class**


- 1. Class A:
  - o Range: 10.0.0.0 10.255.255.255
  - Hosts per Network: 16,777,214
  - Usable Range: 10.0.0.1 10.255.255.254
- 2. Class B:
  - o Range: 172.16.0.0 172.31.255.255
  - Hosts per Network: 65,534
  - Usable Range: 172.16.0.1 172.31.255.254
- 3. Class C:
  - o Range: 192.168.0.0 192.168.255.255
  - o Hosts per Network: 254
  - Usable Range: 192.168.0.1 192.168.0.254

## **Additional Concepts**

- **Subnetting**: Divides networks using subnet masks (e.g., Class C mask: 255.255.255.0).
- DHCP: Automatically assigns IP addresses and network settings.
- IPv4 Size: 32-bit addressing.

# Star Topology Network:

- Star Topology: A network setup where all devices (e.g., PCs) connect to a central hub or switch.
- **Central Switch**: Acts as the main point for communication between devices. Each PC has a direct connection to the switch.
- Common Usage: Widely used in LANs because it is simple to manage and troubleshoot.



## Ethernet Frame Transmission in a Network Using a Switch:

#### 1. Initial Frame Transmission:

- PC0 sends an Ethernet frame to the switch (Switch0).
- The frame contains the destination MAC address (hardware address) of PC1.

#### 2. Switch Behavior:

- The switch examines the destination MAC address in the frame.
- o If the switch does not yet know which port is associated with PC1, it will flood the frame to all connected ports except the one from which it received the frame.
- Every connected device receives the frame, but only PC1 recognizes its own MAC address and processes the frame.
   Other devices ignore it.

## 3. Learning Process:

- When PC1 responds, the switch learns and records which port PC1 is connected to. This is known as building the MAC address table.
- The MAC address table stores the MAC address and corresponding port number for each device on the network.

## 4. Subsequent Communications:

- For future transmissions, the switch uses its MAC address table to directly forward frames to the correct port associated with PC1, without flooding the network.
- This makes communication more efficient, reducing unnecessary network traffic and improving overall network performance.

By following this process, a switch efficiently manages network traffic, optimizing data flow between devices.

# Lab 04:

# 5<sup>th</sup> September

**ACTIVITY**: Class B Subnetting for 30,000 Devices

**Objective:** 

To perform subnetting for a network that needs to accommodate 30,000 devices using Class B IP addressing and implement it on Packet Tracer.

## **Network Requirements:**

• Number of Devices: 30,000

• IP Class: Class B

 Class B Subnet Mask: 255.255.0.0 (or 11111111.11111111.00000000.00000000)

## **Steps for Subnetting:**

- 1. Identifying the Need for Subnetting:
  - The number of devices (30,000) requires more than the default Class B configuration allows without subnetting.
- 2. Finding the Closest Power of 2:
  - The closest power of 2 that satisfies the requirement for 30,000 devices is 2<sup>15</sup> = 32,768 hosts.
  - We will need 15 bits for hosts and reduce 1 bit from the available bits for subnetting.
- 3. Subnet Mask Calculation:
  - Default Class B subnet mask:1111111111111111111000000000.00000000 (/16)
  - To accommodate 30,000 devices, we reduce 1 bit for subnetting:
    - New Subnet Mask:
       1111111.1111111.10000000.00000000 (or /17)
    - Subnet Mask: 255.255.128.0
- 4. Subnetting Calculation:
  - Number of Subnets: 2^(number of changed bits) = 2^1 = 2
     subnets
  - Number of Hosts per Subnet: 2^(unchanged bits) 2 = 2^15 2
     = 32,766 hosts (subtracting 2 for network and broadcast addresses)

#### Subnets:

With the new subnet mask, we can create 2 subnets, each capable of handling up to 32,766 hosts.

Subnet 1 (SN1):

Network Address: 172.168.0.0

Broadcast Address: 172.168.127.255

Usable IP Range: 172.168.0.1 to 172.168.127.254


Subnet 2 (SN2):

Network Address: 172.168.128.0

Broadcast Address: 172.168.255.255

Usable IP Range: 172.168.128.1 to 172.168.255.254

 Test the connectivity between devices within the same subnet and across subnets to verify the configuration.



In the network setup shown above the PCs have the following IPs:

• PCO: 172.168.0.1

• PC1: 172.168.0.2

• PC2: 172.168.128.1

From the ping test results:

- PC0 to PC1 is successful because they are in the same subnet (Subnet 1).
- PCO to PC2 and PC1 to PC2 fail because PC2 is in a different subnet (Subnet 2), and there is no router to handle inter-subnet